L-22 Wiring Information

L-22 (Sercel) is wired in the following manner:

Axis	Signal Response	U77/U
	Tap Down	
VERTICAL, Channel 1	(positive signal on scope)	Α
	Тар Uр	
	(negative signal on scope)	В
NORTH-SOUTH, Channel 2	Tap North	С
	(positive signal on scope)	
	Tap South	
	(negative signal on scope)	D
EAST-WEST, Channel 3	Tap East	Е
	(positive signal on scope)	
	Tap West	
	(negative signal on scope)	F



U77/U Connector